


All Oztec vibrators meet or exceed ACI specification #309

Radius of Action - The most important bit of information needed for complete consolidation.

Radius of Action is the distance from the center of the vibrator to the outer edge, where complete consolidation takes place (see diagram). For quality concrete Oztec lists conservative values for "Radius of Action". Complete consolidation is necessary for low slump concrete with close meshed reinforcement bars, high strength concrete and architectural concrete.

Radius of Action can be twice the listed values when slump is high or super plastisizers are used. It is important these values are used only as a general guide. Specifications are subject to change.



Head Diameter	Radius of Action (R- inches)	$X = 1 \frac{1}{2}$ Times Radius of Action	Amplitude Centerline to Side (inches)	Centrifugal Force (pounds)	Compaction Rate (cu. yds. / hour)
		Steel	Heads		
3/4"	3	5	0.03	155	1-3
1"	4	6	0.04	220	2-4
1 1/4"	5	8	0.04	510	2-5
1 1/2"	6	9	0.05	920	5-8
1 3/4"	6 9	14	0.08	1200	8-16
2"	11	17	0.075	1500	12-20
2 1/2"	13	20	0.08	1850	23-30
		Rubbe	r Heads		
1 7/8"	11	16	0.09	1400	10-18
2 1/2"	14	20	0.12	1900	14-22
2 3/4"	18	27	0.12	2100	25-35
2 3/4" short	15	22	0.12	1100	9-15

All dimensions shown are nominal, actual dimensions may vary. Call for details.