SENCO

Document no. NC1289
Revised July 11, 2011

DHC Supplies, Inc
1095 Spice Islands Dr. #109
Sparks, Nv 89431
800-323-2999
www.dhcsupplies.com

YK0818 (WC150/WC150R)
YK0819 (WC200)
REPAIR KIT INSTRUCTIONS

Kit Contents replace existing parts on tool.

1. Beware of possible sharp edges on bottom lip of the cap due to machined surface.

2. Clean the entire tool motor including the sleeve, piston/driver, and mainbody housing. Relubricate before assembly.

3. Replace piston/driver assembly if damaged.
   - WC150 & WC150R - EA0229
   - WC200 - EA0228

4. Apply Loctite 243 to all screws.